DAILY MAINTENANCE TITAN 575 KUBOTA
Check the engine oil level. Add oil if needed.
Check the high pressure pump oil. Add oil if needed.
Check the oil level in the blower. Add oil if needed.
Check coolant overflow bottle level. Add coolant if needed.
Inspect and clean the recovery tank filters.
Inspect and clean the garden hose screen.
Inspect the truckmount for water and oil leaks, loose electrical connections, etc. and repair as needed.
Lubricate the blower lube port with a HydraMaster-recommended lubricant.

INTERVAL IN HOURS TITAN 575 KUBOTA	
Engine oil and filter	Change engine oil and filter after first 25 hours; afterwards, change the engine oil and filter every 100 hours. (Every 50 hours if operating in high ambient temperatures or heavy use conditions.)*
Blower oil	Change the blower oil after first 100 hours of use. (Every 500 hours thereafter.)**
High pressure pump oil	Change high pressure pump oil after first 50 hours of operation. (Every 500 hours thereafter.)***

SERVICE	8	25	50	75	100	125	150	175	200	225	250	275	300	325	350	375	400	425	450	475	500	525	550	575	600	625	650	675	700	725	750	775	800	825	850	875	900	925	950	975	1000	1025	1050	1075	1100	1125	1150	1175	1200
Vacuum Relief Valve, Clean and Lubricate	CH	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L
Engine Oil and Filter, Oil filter PN 000-049-256, Oil 5W-30 Synthetic*	CH	R			R				R				R				R				R				R				R				R				R				R				R				R
Check for Loose Bolts and Nuts ****			CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH
Check Hoses for Loose fittings and Chafing			CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH
Pump Drive Belt, P/N 000-010-128			CH		CH		CH		CH		CH		R		CH		CH		CH		CH		CH		R		CH		CH		CH		CH		CH		R		CH		CH		CH		CH		CH		R
Flush Chemical System with Vinegar			F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F		F
Blower Drive Belts, P/N 000-010-131	CH	CH	CH		CH				CH				CH				CH				R	CH	CH		CH				CH				CH				CH				R	CH	CH		CH				CH
SERVICE	8	25	50	75	100	125	150	175	200	225	250	275	300	325	350	375	400	425	450	475	500	525	550	575	600	625	650	675	700	725	750	775	800	825	850	875	900	925	950	975	1000	1025	1050	1075	1100	1125	1150	1175	1200
Air Filter, Clean, or Replace as Needed, P/N 000-049-063					C/R				C/R				C/R				C/R				C/R				C/R				C/R				C/R				C/R				R				C/R				C/R
Clean Battery Terminals					C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I
Blower Oil Change, P/N 000-087-034 Pneulube**					R																R																				R								
Engine Fan Belt					CH				CH				CH				CH				CH				CH				CH				CH				CH				R				CH				CH
Fuel Lines											CH										CH										CH										CH								
Spark Plugs, P/N 000-106-174											C/I A										C/I A										C/I A										R								
Fuel Filter, P/N 000-049-257													CH								R				CH												CH				R								
Pump Oil Change, GP Series 100 oil***			R																		R																				R								
SERVICE	8	25	50	75	100	125	150	175	200	225	250	275	300	325	350	375	400	425	450	475	500	525	550	575	600	625	650	675	700	725	750	775	800	825	850	875	900	925	950	975	1000	1025	1050	1075	1100	1125	1150	1175	1200
Change Coolant																					R																				F/R								
Adjust Valve Clearance, Intake and Exhaust .006 in. to .0079 in.																																									A								
Blower Heat Exchanger																																									C/I								

**** Check engine and blower mounting bolts, coupler retaining bolts, exhaust fasteners, etc.

Adjust	A
Check	CH
Clean and Inspect	C/I
Clean and Lubricate	C/L
Clean or Replace	C/R
Flush	F
Replace	R