INTERVAL IN HOURS Titan H2O

SERVICE	8	25	50	75	100	125	150	175	200	225	250	275	300	325	350	375	400	425	450	475	500	525	550	575	600	625	650	675	700	725	750	775	800	825	850	875	900	925	950	975	1000	1025	1050	1075	1100	1125	1150	1175	1200
Engine Oil and Filter, Oil filter PN 000-049-256, Oil 5W-30 Synthetic		R			R				R				R				R				R				R				R				R				R				R				R				R
Check for Loose Bolts and Nuts *			CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH
Vacuum Relief Valve, Clean and Lubricate		C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L	C/L
Check Hoses for Loose fittings and Chafing			CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH		CH
Air Filter, Clean, or Replace as Needed, Part number 000-049-063					C/R				C/R				C/R				C/R				C/R				C/R				C/R				C/R				C/R				R				C/R				C/R
Clean Battery Terminals					C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I				C/I
Spark Plugs, Part number 000-106-174											C/I A										C/I A										C/I A										R								
Spark Plug Wires																																									CH								
Change Coolant																					R																				F R								
Blower Oil Change, Part number 000-087-034 Pneulube					R																R																				R								
Adjust Valve Clearance, Intake and Exhaust .006 in. to .0075 in.																																									A								
Engine Fan Belt, part number 000-010-133					CH				CH				CH				CH				CH				CH				CH				CH				CH				R				CH				CH
Blower Drive Belts Part number 000-010-131	CH	CH	CH		CH				CH				CH				CH				R	CH	CH		CH				CH				CH				CH				R	CH	CH		CH				CH
Fuel Lines											CH										CH										CH										CH								
Fuel Filter, Part number 000-049-257																					R																				R								

* Check engine and blower mounting bolts, coupler retaining bolts, exhaust fasteners, etc.

Adjust	A
Check	CH
Clean and Inspect	C/I
Clean and Lubricate	C/L
Flush	F
Replace	R