



EVM/EVM2/EVM3

REPAIR PARTS CATALOG NO. M50206(P) ISSUED April 2009


ORDERS

Please use Part Numbers when ordering and include the serial number of the machine (stamped on the electrical data plate) to insure that you will receive the correct parts.

Order from your HOST Distributor.

Racine Industries, Inc. 1405 Sixteenth Street

P.O. Box 1648 Racine, WI 53401 USA ☎ 1-262-637-4491
 ☎ 1-800-558-9439
 FAX 1-262-637-0558
 www.hostdry.com




Parts Catalog

SAVE THESE INSTRUCTIONS READ ALL INSTRUCTIONS BEFORE USING THIS MACHINE

WHEN USING ELECTRICAL EQUIPMENT, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

WARNING - TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY

- 1. Do not leave machine when plugged in. Unplug from outlet when not in use and before servicing.
- 2. Do not use outdoors or on wet surfaces.
- 3. Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- 4. Use only as described in manufacturer's Instruction Manual. Use only manufacturer's recommended attachments.
- 5. Inspect cord for damage before each use. Do not use with damaged cord or plug. If machine is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to the manufacturer or authorized repair center.
- 6. Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run machine over cord. Keep cord away from heated surfaces.
- 7. Do not unplug by pulling on cord. To unplug, grasp the plug not the cord.
- 8. Do not handle plug or machine with wet hands.
- 9. Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- 10. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- 11. Turn off all controls before unplugging.
- 12. Do not use the Llberator to clean stairs.
- 13. Do not use to pick up flammable or combustible liquids such as gasoline or use in areas where they may be present.
- 14. Do not use to pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- 15. Do not use for picking up health-endangering dust such as asbestos.
- 16. Do not use as a wet vacuum.
- 17. Do not use without filters in place.
- 18. Connect to a properly grounded outlet only. See Grounding Instructions.
- 19. This machine is to be used with HOST[®] carpet cleaning products only. Use of other cleaning products may damage this machine.




This machine must be grounded. If it should malfunction or break down, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This machine is equipped with a cord having an equipment-grounding conductor and grounding plug. The plug must be inserted into an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.


WARNING: Improper connection of the equipment-grounding conductor can result in the risk of electric shock. Check with a qualified electrician or service person if you are in doubt as to whether the outlet is properly grounded. Do not modify the plug provided with the machine. If it will not fit the outlet, have a proper outlet installed by a qualified electrician.


This machine is for use on a nominal 120 volt circuit, and has a grounded plug that looks like the plug illustrated in **Diagram A**. A temporary adapter that looks like the adapter illustrated in **Diagram B** may be used to connect this plug to a 2-pole receptacle as shown in **Diagram C** if a properly grounded outlet is not available. The temporary adapter should be used only until a properly grounded outlet can be installed by a qualified electrician. The green colored rigid ear, lug, or the like extending from the adapter as illustrated in **Diagram B**, must be connected to a permanent ground outlet box cover. Whenever the adapter is used, it must be held in place by a metal screw as shown in **Diagram C**.

Note: In Canada, the use of a temporary adapter is not permitted by the Canadian Electrical Code.


Safety Instructions	
Grounding Instructions	
Filter Assembly	
Vac Pod Front	
Vac Pod Rear	10
Brush End Cover	12
Back Panel Assembly	14
Handle Assembly	16
Motor Case Assembly	18
Gear Case Assembly	20
Inner Gear Case Assembly	22
Vac Motor Assembly	24
Hood & Nozzle Assembly	26
Caddy	28
Brush & Caddy Mounting Bar	30
Wiring Diagram - 100/120V	
Wiring Diagram - 220/240V	








Code No.	Part No.	Description
1	M50001	Cover, Filter Housing
2	466A	Nut 8-32 (4 Required)
3	H1072	Screw 8-32 x ½" (4 Required)
4	M50002	Filter Housing
5	M30048	Vacuum Hose
6	X206	Cable Tie
7	M30021	Plug, Filter Housing
8	M30022	O-Ring, 2"
9	M30145	Screw 8-32 x 1/2", Thread Forming (4 Required)
10	M50332	Filter, Backing Screen
11	M50333	Filter, White Felt
12	M50334	Filter, Gray Foam
13	M50117	Filter, HEPA Type (Optional)
14	M50040	Filter, Secondary, Black Seal
15	M50039	Filter, Primary, Orange Seal
16	M50116	Separator Assembly
17	M50115	Filter Housing Assembly (Includes Code Nos. 4-9)
18	M50338	Filter Pack, 3-Piece Fine Particle (Includes Code Nos. 10-12)



Code No.	Part No.	Description
1	D31A	Screw 8-32 x ³ / ₈ " (4 Required)
2	M30028	Latch Assembly (2 Required)
3	H1072	Screw 8-32 x ½" (2 Required)
4	M30145	Screw 8-32 x ½" Thread Forming a) Air Deflector to Pod (4 Required) b) Inner Hood to Pod (2 Required) c) Access Plate Assembly to Pod (2 Required)
5	M50377	Access Plate Assembly
6	M30135	Velcro Strip
7	M50120	Bagless Hopper Assembly
8	M50093	Filler Gasket, Front
9	M50198	Gasket, End Plate to Pod
10	M50200	Air Deflector



VAC POD - REAR

Code No.	Part No.	Description
1	M30145	 Screw 8-32 x ¹/₂" Thread Forming a) Flange to Pod (2 Required) b) End Plate/Retainer Assembly to Pod (6 Required) c) Back Cover Plate to Pod (6 Required) d) Nozzle to Pod (2 Required)
2	M30020	Flange
3	M30058	Brush, Filter Cleaning
4	M50068	Decal, Filter Instruction
5	M30057	Strain Relief
6	M50042	Power Cord 120V
7	M50210	Power Cord 230V
8	See Below	Plug
9	M50010	Pod
10	M50092	Gasket
11	M50329	End Plate Retainer Assembly (Includes Code No. 27)
12	M50087	Velcro Strip
13	M30215	Screw 1/4"-20 x 1/2" (2 Required)
14	M50102	Post, Mounting Crevice Tool
15	M50086	Foam Filter
16	M50014	Back Cover Plate
17	M30135	Velcro Strip
18	M50066	Decal, Back Panel Removal
19	M50433	Back Cover Plate Assembly
20	M30027	Hose Cuff
21	M50098	Hose, Vacuum (2" Diameter Black)
22	M30156	Vacuum Elbow Assembly
23	M50442	Vac Hose Assembly
24	M50195	Gasket, Vacuum Motor to Pod
25	M50094	Gasket, Back Panel to Pod (2 Required)
26	M30030	Crevice Tool
27	D31A	Screw 8-32 x 3/8" (2 Required)
28	F210	Washer, Flat (2 Required)
29	M50328	Filter, Foam
	<u>Plugs</u>	
	M7061A	North America
	M4163	Europe

M4206

M4181

M4343

M4241

M4338

M4344

M30515

South Africa/India

United Kingdom


Switzerland

Italy


Israel

Australia


Denmark



Code No.	Part No.	Description
1	M50052	O-Ring, 1 ¹ /"
2	M50109	Backing Plate & Tube Assembly
3	M50012	Plastic End Cover
4	M50156	Screw 8-32 x ¼" (6 Required)
5	M30417	Decal, Power Disconnect
6	M50132	Retainer
7	M50130	Wear Washer
8	M50128	1/4 Turn Stud
9	M50065	Decal, Brush Plate Removal
10	M50087	Velcro Strip
11	M30104	Retaining Ring, ¼" Shaft (2 Required)
12	W529	Washer ½" x ¼" Nylon (2 Required)
13	M50153	Screw 8-32 x ³ / ₈ " (8 Required)
14	M50031	Housing, Bearing (2 Required)
15	M50037	Bearing (4 Required)
16	M50157	Retaining Ring (2 Required)
17	M50028	Hex Shaft, Short (2 Required)
18	D31A	Screw 8-32 x ³ / ₈ " (2 Required)
19	M50053	O-Ring, 3"
20	M50190	Ski, Brush Guard Support
21	M50131	Spring
22	M50081	Skirt
23	M50404	End Plate, Hex Idler Assembly (Includes Code Nos. 1-21)
*Not Illustrated	M50260	1/4 Turn Receptacle




Code No.	Part No.	Description
1	M50060	Switch Plate
2	V703A	Screw #4 x 3/8" (4 Required)
3	M30051	Indicator Lamp
4	M50085	Rocker Switch, Grey
5	M30050	Rocker Switch, Blue
6	M50071	Decal 120V
7	M50231	Decal 220/240V
8	466A	Nut 8-32 (2 Required)
9	M30053	Terminal Block
10	M30147	Screw 8-32 x 7/8" (2 Required)
11	M30054	Terminal Block Cover
12	X415	Nut ¼"-20 (2 Required)
13	F210	Washer 1/8" (2 Required)
14	M50193	Spring
15	U1018A	Washer
16	H1072	Screw 8-32 x 1/2" (2 Required)
17	D31A	Screw 8-32 x ¾" (6 Required)
18	M50008	Back Panel
19	M50032	Cord Hook, Top
20	M50152	Screw 1/4"-20 x 5/6" (2 Required)
21	M50019	Stud, Cord Hook, Brass
22	M50033	Cord Hook, Bottom
23	M50267	Screw 8-32 x ³ / ₁₆ "
24	M50069	Decal
25	M50197	Gasket, "U" Shape
26	M50196	Gasket, Back
27	M50194	Gasket, Nozzle to Pod
28	M50154	Screw 8-32 x ³ / ₁₆ "
29	M5005	Lock Washer
30	M4222	RFI Filter, Vacuum Motor 230V
31	466A	Nut 8-32
*Not Illustrated	M30382	Circuit Breaker 220/240V




Code No.	Part No.	Description
1	M50399	Screw 10-32 x 1¼"
2	M50266	Handle Upright
3	M50057	Handgrip (1 Required)
4	M50269	Set Screw %"-16 x %"
5	L5004	Spring, Ball Retainer
6	W242	Ball 1/4"
7	M2008	Snap Ring
8	M50268	Shaft, Handle Lock
9	M50049	Knob, Knurled
10	M50070	Decal, Round
11	M50152	Screw ¼"-20 x 5%"
12	H1154	Washer, Black Nylon
13	M50054	Nut, Brass
14	M50159	Spring
15	M50046	Temporary Detent Assembly
16	M50151	Screw 10-32 x ¾" (8 Required)
17	M50045	Handle Pivot Sprocket
18	M50201	Decal Strip
19	M30215	Screw ¹ / ₄ "-20 x ¹ / ₂ "
20	F210	Washer
*Not Illustrated	M50270	Handle Assembly (Includes Code Nos. 2, 4-10, 13-15, 18)


Note: (2) Required of each above required unless otherwise noted.




Code No.	Part No.	Description
1	M50076	Support Plate Assembly, Long
2	M30215	Screw ¼"-20 x ½" (4 Required)
3	H1070	Screw ¼"-20 x 1¼" (2 Required)
4	M50022	Exhaust Tube Assembly
5	1213	Cap, Carbon Brush Holder (2 Required)
6	M50367	Carbon Brush 120V (2 Required)
7	M50385	Carbon Brush 220V (2 Required)
8	M50435	Commutator End Bell Assembly
9	D443	Bearing (2 Required)
10	M50363	Armature 120V
11	M50383	Armature 220V
12	M50387	Armature 100V
13	M50428	Bolt (2 Required)
14	60	Nut 10-32 (2 Required)
15	M50365	Field Assembly 120V
16	M50384	Field Assembly 220V
17	M50388	Field Assembly 100V
18	M9008	Grommet
19	F1721	Set Screw (2 Required)
20	M50154	Screw 8-32 x ³ / ₁₆ "
21	M5005	Lock Washer
22	M50166	Groundwire Assembly
23	U1193	RFI Filter, Brush Motor 230V
24	M50427	Motor Housing
25	F2771	Screw 10-32 x ½" (3 Required)
26	D277	Lock Washer (3 Required)
27	M50436	Fan End Bell Assembly
28	M50251	Screw 10-24 x ¾" (3 Required)
29	M50250	Adapter Ring
30	M50429	Motor Assembly 120V
31	M50430	Motor Assembly 230V
32	M50431	Motor Assembly 100V




Code No.	Part No.	Description
1	M50077	Support Plate Assembly, Short
2	M30215	Screw ¼"-20 x ½" (4 Required)
3	M50017	Outer Gear Case
4	M50155	Screw 8-32 x ⁵ / ₈ " (8 Required)
5	M6003A	Bearing, 1/2" (2 Required)
6	M50029	Hex Shaft, Long (2 Required)
7	34A	Woodruff Key (2 Required)
8	U1602A	Bearing (4 Required)
9	M50030	Bearing Housing (2 Required)
10	M50358	Pulley (2 Required)
11	M2008	Retaining Ring (2 Required)
12	M2009A	Flange, Pulley (2 Required)
13	VM56A	Screw 6-32 x ⁵ / ₁₆ " (2 Required)
14	F2771	Screw 10-32 x ½" (2 Required)
15	M50107	Brush Guard Assembly
16	M50191	Ski, Brush Guard Cover
17	M50199	Screw 8-32 x 5/8" (2 Required)




Code No.	Part No.	Description
1	M12010	Gasket, Inner Gear Case
2	M50351	Snap Ring (2 Required)
3	M50357	Gear, Left Hand
4	M50356	Gear, Right Hand
5	U1605A	Key (2 Required)
6	M50353	Inner Gear Case
7	M50352	Bearing (2 Required)
8	M50354	Flange, Pulley Spacer (2 Required)
9	M12013	Pin 1/8" x 3/4" (2 Required)
10	M12011A	Screw 10-32 x ¹³ / ₁₆ " (9 Required)
11	M50355	Pulley Shaft (2 Required)
12	M50038	Timing Belt, Short
13	M50041	Timing Belt, Long
14	M50378	Inner Gear Case Assembly (Includes Code Nos. 2-9, 11)




Code No.	Part No.	Description
1	M50097	Hose, 2" Dia Clear 14.75" Long
2	M50100	Hose, 1" Dia Clear 30" Long
3	X206	Cable Tie (2 Required)
4	M30145	Screw 8-32 x 1/2" Thread Forming (2 Required)
5	M30216	Screw 10-16 x %" Self Tapping (2 Required)
6	M50055	Plate, Motor Mounting
7	M50113	Vac Motor Assembly 120V
8	M50209	Vac Motor Assembly 230V
9	M30052	Switch, Clean Filters



Code No.	Part No.	Description
1	M50009	Pickup Nozzle
2	M50095	Gasket (2 Required)
3	M50091	Gasket, Gear Case Bottom
4	M50096	Gasket (2 Required)
5	M50020	Hood, Inner
6	466A	Nut 8-32 (2 Required)
7	M30145	Screw 8-32 x ½" Thread Forming a) Pickup Nozzle to Inner Hood (4 Required) b) Hood to Pod (2 Required)
8	M30283	Gasket, Double Arch
9	U1018A	Washer 1/2" (2 Required)
10	V115	Screw 10-24 x 7/16" (2 Required)
11	M50347	Inner Hood Nozzle Assembly (Includes Code Nos. 1-5, 7a, 8)



Code No.	Part No.	Description
1	M50011	Caddy
2	M50124	Lock Bolt (2 Required)
3	M50140	Spring (2 Required)
4	M50125	Lock Lever (2 Required)
5	M50139	Knob (2 Required)
6	M50145	Locating Strip
7	M50146	Screw 10-32 x 1" (3 Required)
8	M50136	Axle Assembly
9	H1070	Screw 1/4"-20 x 11/4" (4 Required)
10	F817	Washer, Nylon (4 Required)
11	F507	Cotter Pin (2 Required)
12	M50141	Hub Cap (2 Required)
13	F824	Wheel (2 Required)
14	M50337	Wheel & Hub Cap Assembly (Includes Code Nos. 12, 13)
15	M50403	Caddy Assembly (Includes Code Nos. 1-13)




Code No.	Part No.	Description
1	M50133	Caddy Accessory Pack Mounting Bar (2 Required)
2	H1070	Screw ¼-20 X 1¼" (8 Required)
3	See Below	Brush (2 Required)


Brushes (Assembly Contains 2)

M50221	Brush Assembly, White (Standard)
M10222	Brush Assembly, Beige (Soft)
M50223	Brush Assembly, Zebra (Firm)
M50263	Brush Assembly, Red (Firm, for Grouted Tile Only)





Wiring Diagram 100/120V



Wiring Diagram 220/240V

© 2009 **Racine Industries, Inc.** 1405 Sixteenth Street P.O. Box 1648 Racine, WI 53401 USA

 ☎
 (800) 558-9439

 ☎
 (262) 637-4491

 FAX
 (262) 637-0558

 www.hostdry.com



HOST, Liberator and extractorVAC are registered trademarks of Racine Industries, Inc., Racine, Wisconsin USA.

M50206(P)